

GXO 工程转换指南


此转换指南描述了如何把 GXO 工程转换到 GXU 工程。支持可转换的 GXO 工程版本从 **Vijeo Designer Full V6.1** 到 **Vijeo Designer Full V6.2 SP1**。转换后的目标工程版本是 **Vijeo Designer Basic V1.0**。

如果你VJD6.2没有升级到SP2，工程还是可以转到BASIC上的，但是升级了SP2就不能转了

第一步：从 **Vijeo Designer Full** 版本软件中导出 **GXO** 工程

在 **Vijeo Designer** 软件的“**导航窗口**”中，鼠标右键点击 **GXO** 工程。

选择“**导出工程**”选项导出并保存 **GXO** 工程。




第二步：在 **Vijeo Designer Basic** 版本软件中导入 **GXO** 工程到

在 **Vijeo Designer** 软件的“**导航窗口**”中，鼠标右键点击 **Vijeo-Manager**。

选择“**导入工程**”选项导入 **GXO** 工程。

在 **Vijeo Designer Basic** 版本软件中，工程中的 **GXO** 型号在导入时的会自动升级到默认的 **GXU** 型号。



最后一步：如果需要，根据你手上实际拥有的 **GXU** 型号，在 **Vijeo Designer Basic** 版本软件中更新工程中的 **GXU** 型号。


GXO Project Conversion Guide

This conversion guide is to describe how to convert GXO project to GXU project. The supported project version of GXO is from **Vijeo Designer Full V6.1** through **Vijeo Designer Full V6.2 SP1**. The targeted project version of GXU is **Vijeo Designer Basic V1.0**.

First Step: Export GXO project from Vijeo Designer Full version

Right Click the mouse on GXO project in the **Navigator** of Vijeo Designer configuration windows.

Select “**Export Project...**” option to export and save the GXO project.




Second Step: Import GXO project into Vijeo Designer Basic version

Right Click the mouse on **Vijeo-Manager** in the **Navigator** of Vijeo Designer configuration windows.

Select “**Import Project...**” option to import the GXO project.

The GXO model of the project is automatically updated to default GXU model when the project is imported into Vijeo Designer Basic version.



The Last Step: Update the GXU model of the project in Vijeo Designer Basic version according to the actual GXU model on your hand if needed.